



LIFTING DIAGRAM

NOTES:

1. Drill and tap for 2 1/2" recessed pipe plug.
2. For location and elevation of sign structure see Project Plans.
3. Sign support post shall be raked out of plumb with leveling nuts to make the bottom of the sign frame level.
4. At final position of post, top and bottom nuts shall be tightened against base plate.
5. For "General Notes", see Standard Plan S101.

DIST	COUNTY	ROUTE	POST MILES TOTAL PROJECT	SHEET NO.	TOTAL SHEETS

Stanley P. Johnson  
REGISTERED CIVIL ENGINEER

May 20, 2011  
PLANS APPROVAL DATE

Stanley P. Johnson  
No. CS7793  
Exp. 3-31-12  
CIVIL  
STATE OF CALIFORNIA

THE STATE OF CALIFORNIA OR ITS OFFICERS OR AGENTS SHALL NOT BE RESPONSIBLE FOR THE ACCURACY OR COMPLETENESS OF SCANNED COPIES OF THIS PLAN SHEET.

STATE OF CALIFORNIA  
DEPARTMENT OF TRANSPORTATION

**OVERHEAD SIGN-TRUSS  
SINGLE POST TYPE  
LAYOUT  
UNBALANCED BUTTERFLY  
CHANGEABLE MESSAGE SIGNS  
MODEL 510**

NO SCALE

S120